
Technical Bulletin



TB No	TB14	Metrodata AP Range PSU Change
No of pages	1	For use by Service Engineers only.
June 2002	Part no	tbc

USAGE!

This Bulletin is for the assistance of qualified Service Engineers, and the work described should not be attempted by End Users of the products.

WARNING !

The product contains static sensitive devices. Installation should be carried out at a properly equipped anti-static station by personnel wearing anti-static straps.

INTRODUCTION

This Bulletin describes the procedure for replacing a 100-250 VAC / 50-400 Hz PSU for the AP range of products.

REMOVING THE PSU

- 1) Remove the mains cable and ensure that there is nothing that may cause static to damage the unit during this process. Where possible please endeavor to wear an anti static wristband.
- 2) Unscrew the four slot head thumbscrews on the back of the power supply unit. Depending on the tightness of these you may need to use a flat blade screwdriver.
- 3) Using the handles supplied pull the power supply towards you until it is outside of the unit.

INSTALLING THE REPLACEMENT PSU

- 1) Holding the handles push the power supply back into the chassis until you feel it click firmly into place.
- 2) Screw the thumbscrews back into place until they are finger tight then give them one more turn with a flat blade screwdriver.
- 3) Replace mains cable into the power connector.
The power supply is now ready for use, though the unit may have to be reconfigured to operating requirements before it can be returned to service.